




Model BTD142HW Parts List

A = Standard Equipment

○ = Circuit Diagram

Fig.	Part No.	Description	Q'ty	Unit
1	188226-5	HOUSING SET	1	
	D10	INC. 42		
2	863260-3	BTD142 NAME PLATE	1	
3	266130-9	TAPPING SCREW BIND PT 3X16	8	PC.
6	419041-9	F/R CHANGE LEVER	1	PC.
7	650564-0	SWITCH TG553FSB-1	1	PC.
8	652045-0	+PAN HEAD SCREW M3.5X5	2	PC.
9	643812-4	TERMINAL	1	PC.
10	231951-8	RING SPRING 11	1	PC.
11	267085-1	FLAT WASHER 12	1	PC.
12	233005-7	COMPRESSION SPRING 13	1	PC.
13	324420-7	SLEEVE	1	PC.
14	421913-6	BUMPER	1	PC.
15	419042-7	HAMMER CASE COVER	1	PC.
16	154590-6	HAMMER CASE COMPLETE	1	PC.
17	261108-7	NYLON WASHER 14	1	PC.
18	216001-0	STEEL BALL 3.5	2	PC.
19	324432-0	ANVIL M	1	PC.
20	324583-9	HAMMER	1	PC.
21	216001-0	STEEL BALL 3.5	24	PC.
22	267175-0	FLAT WASHER 24	1	PC.
23	233430-2	COMPRESSION SPRING 24	1	PC.
24	267766-7	CUP WASHER 14	1	PC.
25	216011-7	STEEL BALL 5.6	2	PC.
26	226336-1	SPUR GEAR 22	2	PC.
27	324552-0	SPINDLE	1	PC.
28	256253-1	PIN 5	2	PC.
29	267212-0	FLAT WASHER 12	1	PC.
30	227150-8	INTERNAL GEAR 51	1	PC.
31	211140-1	BALL BEARING 6901LLB	1	PC.
32	213507-9	O RING 40	1	PC.
33	154769-9	BEARING BOX COMPLETE	1	PC.
	D10	INC. 31		
34	638396-5	YORK UNIT	1	PC.
35	619172-6	ARMATURE	1	PC.
36	194159-4	CARBON BRUSH CB-436	1	SET
37	638387-6	BRUSH HOLDER COMPLETE	1	PC.
	C10	231696-8	TORSION SPRING R	1 PC.
	C20	231697-6	TORSION SPRING L	1 PC.
38	263032-0	RUBBER PIN 4	2	PC.
39	418982-6	REAR COVER	1	PC.
40	266130-9	TAPPING SCREW BIND PT 3X16	2	PC.
41	631693-8	LIGHT CIRCUIT	1	PC.

42		188226-5	HOUSING SET	1	
	D10		INC. 1		
43		810292-1	CAUTION LABEL	1	PC.
A01		DC18RA	DC18RA FAST CHARGER	1	
A02		BL1815	BATTERY BL1815, 18V	2	
A03		824774-7	PLASTIC CARRYING CASE	1	PC.
A03	C10	324679-6	SHAFT	1	PC.
A03	C20	417724-5	LATCH	2	PC.
A03	C30	419216-0	HANDLE	1	PC.
A04		450128-8	BATTERY COVER	1	PC.